

LCD  
"Quick"  
Buttons

Use to toggle  
between Specific  
LCD Information

**Hour meter icon:** push and release to view: Engine run time hour meter (ENG),  
Mower deck run time hour meter, eraseable job timer (TMR), Time of Day Clock  
**Tach/Volt:** push and release to view: tachometer (RPM) or Volt Meter (VOLTS)

**Wrench icon:** push and release to view: Maintenance schedule

**Speedometer icon:** push and release to view: speedometer (SPD),  
odometer (DST), trip odometer (TRP), Area counter (AR)

LCD information  
center

Critical  
condition  
warning LEDs

LED safety  
indicators

PTO/Mower Engagement Knob  
Pull up to engage mower blades  
Depress to disengage

"Have pad print on the knob"

Mower Deck Lift


**Picture of up button:** Depress to raise  
**Picture of don button:** Depress to lower

Show side profile of knob up -

Parking brake  
on/off button

Overlay to include Icons

Art to be inclusive of all features with  
flexibility for GDI to edit test for each OEM



Service Alert  
access/reset button

Engine start and stop button  
Depress and hold down to engage starter, release when started  
Depress to shut engine off

Headlight  
on/off  
button

OK to start LED  
GREEN LED ICON: indicates engine is ready to start  
RED LED ICON: Indicates unsafe condition exists  
(drive levers not in neutral, Parking brake not applied on, PTO not disengaged or operator not in seat)