

LCD
"Quick"
Buttons

Use to toggle
between Specific
LCD Information

Hour meter icon: push and release to view: Engine run time hour meter (ENG),
Mower deck run time hour meter, eraseable job timer (TMR), Time of Day Clock
Tach/Volt: push and release to view: tachometer (RPM) or Volt Meter (VOLTS)

Wrench icon: push and release to view: Maintenance schedule

Speedometer icon: push and release to view: speedometer (SPD),
odometer (DST), trip odometer (TRP), Area counter (AR)

LCD information
center

Critical
condition
warning LEDs

LED safety
indicators

PTO/Mower Engagement Knob
Pull up to engage mower blades
Depress to disengage

"Have pad print on the knob"

Mower Deck Lift


Picture of up button: Depress to raise
Picture of don button: Depress to lower

Show side profile of knob up -

Parking brake
on/off button

Overlay to include Icons

Art to be inclusive of all features with
flexibility for GDI to edit test for each OEM



Service Alert
access/reset button

Engine start and stop button
Depress and hold down to engage starter, release when started
Depress to shut engine off

Headlight
on/off
button

OK to start LED
GREEN LED ICON: indicates engine is ready to start
RED LED ICON: Indicates unsafe condition exists
(drive levers not in neutral, Parking brake not applied on, PTO not disengaged or operator not in seat)